

Items marked with an asterisk (\*) are included in the electrical kit only. We have made an effort to show the revision numbers for sheets where new drawings have been issued, but you should consult the revision list to be certain.

A1	No. 101	Inboard Profile	A46*	No. 116	Electrical System Details
A2E	No. 102	Main Landing Gear Assy & Inst.	AA1	No. 160	Antenna Installation
A3E	No. 152	Fuel System & Engine Hoses Inst.	AA2	No. 162	DME/Transponder Antenna Assembly
A4A	No. 104	Nose Gear Bay Doors Installation	AA3	No. 161	Ferrite-Foil Antenna Assembly
A5D	No. 105	Nose Gear Control Assembly	B1B	No. 201	Wing Assembly, Sheet 1
(A6H)	N/A		B2K	No. 201	Wing Assembly, Sheet 2
A7B	No. 107	Canopy Assembly	B3D	No. 201	Wing Assembly, Sheet 3
A8B	No. 108	Center Console Assembly	B4B	No. 201	Wing Assembly, Sheet 4
A9C	No. 131	Engine Controls Installation	B5A	No. 202	Wing Tip Bow & Other Details
A10B	No. 132	Exhaust System Installation	B6B	No. 203	Aileron & Flap Assembly
A11E	No. 133	Engine Baffling Installation	B7B	No. 204	Aileron & Flap Hinge Installation
A12	No. 118	Covering Draft (to be replaced)	B8B	No. 205	Main Wing Spar
A13E	No. 134	Cowling Installation	B9F	No. 206	Auxiliary Wing Spars
A14	No. 114	Equipment Frame No. 1	B10G	No. 207	Wing Rib Station 1
A15B	No. 145	Instrumentation & Installation	B11F	No. 208	Wing Rib Station 2
A16B	No. 117	Trim Tab Ctl & Parking Brake Valve Inst	B12B	No. 209	Wing Rib Station 3
A17D	No. 120	Elevator Controls Installation	B13A	No. 210	Wing Rib Station 4
A18C	No. 126	Control Stick Assembly	B14A	No. 211	Wing Rib Station 5
A19C	No. 121	Fuel Tank Installation	B15A	No. 212	Wing Rib Station 6
A20	No. 150	Control Cables	B16D	No. 213	Wing Rib Sta 7 & Aileron Rib Sta 14
A21	No. 123	Seat Belt Mount Installation	B17A	No. 214	Wing Rib Sta 8 & Aileron Rib Sta 9
A22	No. 107A	Canopy Assy & Inst.—"Nustrini"	B18	No. 215	Wing Ribs Stations 9, 10 & 11
A23	No. 109A	Windshield—"Nustrini" (eliminate)	B19	No. 216	Wing Ribs Stations 12, 13 & 14
A24	No. 124	Windshield Installation	B20	No. 217	Aileron Ribs
	No. 124A	Windshield Installation—"Nustrini"	B21	No. 218	Wing Rib Sta 2-1/2 & Flap Ribs Sta 2
A25	No. 122	Rudder Controls Installation	C1	No. 301	Fuselage Draft
A26	No. 151	Pitot Static System	C2	No. 306	Fuselage Assembly
A27	No. 158	Vacuum System Installation	C3P	No. 302	Fuselage Frame No. 1
A28	No. 155	Instrument Panel Installation		No. 303	Fuselage Frame No. 2
A29	No. 156	Seats and Harness Installation		No. 304	Fuselage Frame No. 3
A30A	No. 153	Flap Indicator Installation		No. 305	Fuselage Frame No. 4
A31	No. 157	L.H. Throttle Installation	C4H	No. 310	Fuselage Frame No. 5
A32	No. 130	Paint Schemes, Sheet 1		No. 311	Fuselage Frame No. 6
A33	No. 130	Paint Schemes, Sheet 2		No. 311	Fuselage Frame No. 6 Diagonal
A34	No. 130	Paint Schemes, Sheet 3		No. 312	Fuselage Frame No. 7
A35	No. 130	Paint Schemes, Sheet 4	C5	No. 301B	Fuselage Jig
A36	No. 130	Paint Schemes, Sheet 5		No. 313	Fuselage Frame No. 8-11
A37	No. 130	Paint Schemes, Sheet 6	C6	No. 320	Battery Box
A38*	No. 116-1	Main Power Circuit	C7	No. 321	Fuselage Jig
A39*	No. 116-8	Landing Gear Circuit	C8	No. 305B	Fuselage Frame No. 4—"Nustrini"
A40*	No. 116-9	Audio Circuit		No. 314	Fuselage Frame No. 2 Diagonal
A41*	No. 116-2	Fuel Pump Circuit	C9	No. 315	Cockpit Flooring
	No. 116-3	Pitot Heat Circuit	D1A	No. 401	Elevator & Stabilizer Installation
	No. 116-4	Turn & Bank Circuit	D2F	No. 402	Elevator & Stabilizer Assy, Sheet 1
	No. 116-5	Anticollision Light Circuit	D3D	No. 402	Elevator & Stabilizer Assy, Sheet 2
	No. 116-6	Navigation Light Circuit	D4C	No. 403	Elevator Ribs & Tip Bow
	No. 116-7	Landing Light Circuit	D5D	No. 404	Elevator & Stabilizer Ribs
	No. 116-10	Flap Circuit	D6F	No. 405	Elevator & Stabilizer Ribs
	No. 116-11	Panel Light Circuit	D7B	No. 406	Elevator & Stabilizer Spars
	No. 116-12	Glareshield Light Circuit	D8A	No. 410	Fin & Rudder Installation, Sheet 1
A42*	No. 116-13	Instrument Circuit	D9A	No. 410	Fin & Rudder Installation, Sheet 2
	No. 116-14	Instrument Circuit	D10A	No. 411	Fin & Rudder Assembly
	No. 116-15	Autopilot Circuit	D11A	No. 412	Fin and Rudder Spars
	No. 116-16	Carburetor Ice Detector Circuit	D12E	No. 413	Fin Ribs
	No. 116-17	Spare Wires	D13G	No. 414	Rudder Ribs
	No. 116-18	Fuelgard Circuit	D14F	No. 415	Fin & Rudder Spars, Etc.
A43*	No. 116	Electrical System Details	E1B	No. 550-1	Oleo Shock Absorber Strut
A44*	No. 116	Electrical System Details		No. 520-2	Housing
A45*	No. 116	Electrical System Details	E2E	No. 502	Main Landing Gear Leg
			E3B	No. 503	Main Landing Gear Arm
			EE1E	No. 512	Main Landing Gear Screwjack Sleeve
			EE2C	No. 513	Main Landing Gear Screwjack Rod
			EE3B	No. 504-2	Upper Side Load Strut
				No. 504-3	Upper Side Load Strut

EE4A	No. 520-5	Main Gear Drive Shaft	G3	No. 840	Cowling (replace)
EE5A	No. 520-6A	Vertical Drive Shaft	G4A	No. 840	Cowling (replace)
EE6	No. 503-9	Seal Ring	G5B	No. 701	Control Stick Support
EE7	No. 503-23	Spacer		No. 702	Control Stick
EE8	No. 551	Oleo Orifice Fitting	G6C	No. 703-1	Right Hand Rudder Pedal Assembly
EE9	No. 552	Oleo Rebound Damper		No. 703-2	Left Hand Rudder Pedal Assembly
EE10	No. 553	Oleo Cylinder	G7D	No. 740	Hoses, Hose Assemblies, and Tubes
EE11	No. 554	Oleo Nut	G9B	No. 828-1	Seat
EE12	No. 555-1	Oleo Piston		No. 828-2	Seat
EE13	No. 555-2	Piston End	G10A	No. 728A	Aft Fuel Tank
EE14	No. 555-3	Piston	G11A	No. 729A	Front Fuel Tank
EE15	No. 556-1	Bushing	G12B	No. 797-1	Canopy Frame
	No. 556-2	Bushing	G13C	No. 828	Seat Tracks
EE16A	No. 504-1A	Lower Side Load Strut	G14A	No. 832A	Landing Gear Crank Cover
EE17	No. 503-24	Spacer		No. 831-15	Quadrant Cover
EE18	No. 520-3	Spur Gear	G15A	No. 833A	Center Console Cover—Front
EE19	No. 520-4	Miter Gear & Shaft	G16A	No. 834A	Center Console Cover
EE20	No. 520-7	Miter Gear	G17A	No. 835A	Center Console Cover—Rear
F1F	No. 601	Nose Gear Assembly	G18	No. 804	Carburetor Air Intake (eliminate)
F2	No. 654	Nose Gear Trunnion	G19A	No. 836	Main Landing Gear Doors
F3	No. 618	Nose Gear Upper Drag Strut	G20B	No. 814	Wing Fairings
	No. 653	Nose Gear Upper Cylinder	G21D	No. 857	Tail Group Fairings, Etc.
F4	No. 613	Nose Gear Fork	G22	No. 797-2	Canopy Frame—"Nustrini"
F5	No. 654A	Nose Gear Trunnion	G23	No. 828-3	Seat Bottom Cushion
F6	No. 618A	Nose Gear Upper Drag Strut	G24	No. 828-4	Seat Back Cushion
FF1	No. 602-1	Spring	G25	No. 831-2	Center Console Panel
FF2	No. 602-2	Spacer	G26	No. 841-1	Instrument Panel
FF3	No. 602-3	Retainer	G27	No. 831-1	Center Console Panel Assy & Inst (to 'A' series?)
FF4	No. 603	Screwjack End	G28	No. 884	Glare Shield
FF5B	No. 604A	Nose Gear Screwjack Assembly	G29	No. 707-3	Dynafoal (Type II) Engine Mount
FF6	No. 605	Nose Gear Adjustment Screw	G30	No. 858-1	Nose Gear Bay Cover Assembly
FF7B	No. 606A	Nose Gear Screwjack Sleeve	GG1	No. 720	Engine Mount Lug
FF8	No. 607	Nose Gear Screwjack Screw	GG2	No. 708	Nose Gear Drag Strut Support
FF9	No. 608	Nose Gear Orifice Support Tube	GG3	No. 742	Flap Hinge
FF10	No. 609	Nose Gear Orifice Support Fitting	GG4	No. 743	Flap Hinge and Arm
FF11	No. 610-1	Nose Gear Orifice	GG5	No. 744	Flap and Aileron Hinge
FF12	No. 610-2	Nose Gear Rebound Damper	GG6	No. 745	Aileron Hinge
FF13B	No. 663	Nose Gear Rocker Arm	GG7	No. 746	Aileron Hinge
FF14B	No. 664	Stop	GG8	No. 747	Aileron Control Arm and Hinge
FF15C	No. 665	Eye Bolt	GG9	No. 748	Aileron Hinge
FF16	No. 616	Nose Gear Upper Ring Nut	GG10	No. 749	Aileron Hinge
FF17	No. 619	Nose Gear Lower Drag Strut	GG11	No. 750	Elevator Control Arm
FF18B	No. 620	Nose Gear Steering Arm	GG12	No. 751	Rudder Control Arm
FF19	No. 621	Nose Gear Control Rod	GG13	No. 752	Elevator Hinge
FF20	No. 651	Nose Gear Orifice Assembly	GG14	No. 753	Fin Hinge
FF21	No. 652-1	Nose Gear Lower Cylinder Assembly	GG15	No. 754	Fin Hinge
FF22	No. 652-2	Nose Gear Lower Cylinder	GG16	No. 755	Stabilizer Hinge
FF23	No. 652-3	Nose Gear Fork Mounting Plate	GG17	No. 756	Elevator Hinge
FF24	No. 655	Nose Gear Lower Ring Nut	GG18	No. 757	Rudder Hinge
FF25B	No. 656	Nose Gear Cap Fitting	GG19	No. 759A	Aileron Bellcrank Support—Bottom
FF26	No. 657	Nose Gear Lower Bushing	GG20	No. 759B	Aileron Bellcrank Support—Top
FF27	No. 658	Nose Gear Bushing	GG21	No. 761	Rudder Pedal Support
FF28	No. 659	Nose Gear Piston Bushing	GG22	No. 762	Elevator Control Arm Support
FF29	No. 660A	Nose Gear Guide and Stop	GG23	No. 764	Control Stick Assembly Support
FF30	No. 614	Nose Gear Axle	GG24	No. 774	Fin Hinge
FF31	No. 615	Nose Gear Axle Nut	GG25	No. 775	Elevator Trim Arm
FF32	No. 670	Spacer	GG26	No. 823	Canopy Stop
FF33	No. 622	Screwjack End	GG27A	No. 875-1	L.H. Throttle Control Lever Assembly
FF34	No. 619A	Nose Gear Lower Drag Strut	GG28B	No. 876	Drain Valve Fitting
FF35	No. 623	Bushing	GG29C	No. 877	Switch Support
FF36	No. 661-2	Upper Torque Link	GG30	No. 760	Elevator Control Bellcrank
FF37	No. 662-2	Lower Torque Link	GG31	No. 765	Flap Control Tube Support
G1B	No. 707-1	Conical Engine Mount	GG32	No. 780	Elevator Control Rod Assembly
G2C	No. 707-2	Dynafoal (Type 1) Engine Mount			

GG33	No. 715	Elevator Control Rod End	GG96A	No. 859-2	Bracket
GG34	No. 716	Elevator Control Rod End Fitting		No. 859-3	Bracket
GG35	No. 712	Aileron Control Rod End	GG97A	No. 859-4	Bracket
GG36	No. 714	Aileron Control Rod End	GG98	No. 792	Canopy Track
GG37	No. 726	Flap Control Tube Support	GG99	No. 731A	Fuel Tank Filler
GG38	No. 816	Mounting Bracket	GG100A	No. 868	Canopy Pin
GG39	No. 817	Canopy Fitting	GG101	No. 850	Channel-Nut
GG40C	No. 800	Canopy Closing Hook	GG102	No. 758	Aileron Bellcrank
	No. 800A	Canopy Closing Hook—"Nustrini"	GG103	No. 781	Aileron Control Rod
GG41A	No. 801A	Canopy Latch Spring	GG104A	No. 809-1	Jack Pad Fitting
GG42A	No. 831-31	Quadrant Spacer	GG105	No. 724-2	Bracket
GG43	No. 718	Control Stock Connecting Rod	GG106	No. 724-3	Guard
GG44B	No. 820	Landing Gear Crank	GG107A	No. 866	Bracket
GG45B	No. 821-2	Spindle	GG108	No. 725-2	Bracket
GG46B	No. 822	Landing Gear Crank Handle	GG109	No. 725-3	Guard
GG47B	No. 863	Bracket	GG110	No. 851-1	Control Stick Removal Modification
GG48B	No. 864	Bracket	GG111	No. 851-2	Nut
GG49B	No. 845	Channel	GG112	No. 851-3	Receptacle
GG50B	No. 831-30	Flap Position Switch Support	GG113	No. 851-4	Connector
GG51A	No. 825A	Elevator Balance Weight Support	GG114	No. 799	Canopy Closing Handle
GG52	No. 838-2	Elevator Balance Weight	GG115	No. 821-3A	Collar
GG53A	No. 860	Pushrod	GG116A	No. 846	Channel
GG54A	No. 861	Pushrod	GG117	No. 777	Canopy Slide Tube
GG55A	No. 862	Pushrod	GG118	No. 717-1	Nose Gear Screwjack Support
GG56A	No. 865	Pushrod	GG119	No. 717-2	Bracket
GG57A	No. 870	L.H. Throttle Pivot Cover	GG120	No. 717-3	Retainer
GG58A	No. 871	L.H. Throttle Pivot Fitting	GG121	No. 854	Flap Actuator Support
GG59A	No. 872-1	L.H. Throttle Torque Tube Assembly	GG122	No. 709-2	L.H. Torsion Tube Assembly
GG60A	No. 873-1	L.H. Throttle Pushrod	GG123	No. 710-1A	Coupling
GG61A	No. 874	L.H. Throttle Pushrod	GG124	No. 711-1A	Torsion Tube
GG62A	No. 705	Lower Side Load Strut Pin		No. 711-2A	Torsion Tube
GG63A	No. 706	Upper Side Load Strut Pin	GG125	No. 709-1	Torsion Tube Assembly
GG64A	No. 773	Side Load Strut Mount Spacer	GG126	No. 806	Outboard Lap Belt Mount
GG65	No. 719	Main Landing Gear Arm Pin	GG127	No. 713A	Flap Control Rod
GG66	No. 723	Main Landing Gear Oleo Pin	GG128	No. 727	Static Port Fitting
GG67	No. 772	Side Load Strut Mount	GG129	No. 729-10	Tank Vent Fitting
GG68	No. 721	Main Landing Gear Arm Bushing	GG130	No. 729-11	Filler Fitting
GG69C	No. 767	Main Landing Gear Forward Mount	GG131	No. 729-12	Fuel Cap
GG70	No. 768	M. L. Gear Forward Anchor Plate	GG132	No. 730A	Fuel Tank Sender Fitting
GG71	No. 770	M. L. Gear Forward Mount Bushing	GG133	No. 829-10	Outboard Seat Belt Cable Assembly
GG72C	No. 766	Main Landing Gear Aft Mount	GG134	No. 829-11	Inboard Seat Belt Cable Assembly
GG73	No. 771	Main Landing Gear Aft Anchor Plate	GG135	No. 829-12	Shoulder Belt Clip
GG74	No. 769	M. L. Gear Aft Mount Bushing	GG136	No. 831-3	Throttle Control Lever Assembly
GG75	No. 782	Trim Tab Control Wheel	GG137	No. 831-4	Propeller Control Lever Assembly
GG76	No. 783	Trim Tab Control Channel	GG138	No. 831-5	Mixture Control Lever Assembly
GG77A	No. 784	Trim Tab Control Sleeve	GG139	No. 831-6	Quadrant Bracket
GG78B	No. 785	Trim Tab Control Screw	GG140	No. 831-7	Quadrant Bracket Assembly
GG79A	No. 786A	Trim Tab Control Mount Plate	GG141	No. 831-8	Quadrant Spacer
GG80A	No. 788A	Trim Tab Control Mounting Bracket	GG142	No. 831-9	Quadrant Spacer
GG81	No. 776	N. G. Drag Strut Support Anchor Plate	GG143	No. 831-11	Quadrant Spacer
GG82A	No. 856A	Engine Mount Lug Anchor Plate	GG144	No. 831-13	Quadrant Friction Knob
GG83	No. 839	Engine Mount Lug Anchor Plate	GG145	No. 831-14	Throttle Position Switch Cam
GG84	No. 802	Canopy Roller Mount			
GG85	No. 803	Canopy Roller			
GG86	No. 794	Canopy Roller Mount			
GG87	No. 795	Canopy Roller			
GG88	No. 733	Fuel Tank Bands			
GG89A	No. 805	Center Lap Belt Mount			
GG90B	No. 807	Shoulder Belt Mount			
GG91A	No. 818	Aileron Stop			
GG92A	No. 791-1	Pitot Tube Mast			
GG93	No. 735	Aft Fuel Tank Band Mount			
GG94	No. 734	Fuel Tank Band Mount			
GG95A	No. 869	Canopy Fitting—"Nustrini"			

No. 101	A1	Inboard Profile	No. 214	B17A	Wing Rib Sta 8 & Aileron Rib Sta 9
No. 102	A2E	Main Landing Gear Assy & Inst.	No. 215	B18	Wing Ribs Stations 9, 10 & 11
No. 104	A4A	Nose Gear Bay Doors Installation	No. 216	B19	Wing Ribs Stations 12, 13 & 14
No. 105	A5D	Nose Gear Control Assembly	No. 217	B20	Aileron Ribs
No. 107	A7B	Canopy Assembly	No. 218	B21	Wing Rib Sta 2-1/2 & Flap Ribs Sta 2
No. 107A	A22	Canopy Assy & Inst.—"Nustrini"	No. 301	C1	Fuselage Draft
No. 108	A8B	Center Console Assembly	No. 301B	C5	Fuselage Jig
No. 109	N/A	Windshield	No. 302	C3P	Fuselage Frame No. 1
No. 109A	A23	Windshield—"Nustrini" (eliminate)	No. 303	C3P	Fuselage Frame No. 2
No. 110	N/A	Canopy	No. 304	C3P	Fuselage Frame No. 3
No. 114	A14	Equipment Frame No. 1	No. 305	C3P	Fuselage Frame No. 4
No. 116		Electrical System	No. 305B	C8	Fuselage Frame No. 4—"Nustrini"
No. 117	A16B	Trim Tab Control & Parking Brake Valve Installation	No. 306	C2	Fuselage Assembly
No. 118	A12	Covering Draft	No. 310	C4H	Fuselage Frame No. 5
No. 120	A17D	Elevator Controls Installation	No. 311	C4H	Fuselage Frame No. 6
No. 121	A19C	Fuel Tank Installation	No. 311	C4H	Fuselage Frame No. 6 Diagonal
No. 122	A25	Rudder Controls Installation	No. 312	C4H	Fuselage Frame No. 7
No. 123	A21	Seat Belt Mount Installation	No. 313	C4H	Fuselage Frame No. 8-11
No. 124	A24	Windshield Installation	No. 314	C8	Fuselage Frame No. 2 Diagonal
No. 124A	A24	Windshield Installation—"Nustrini"	No. 315	C9	Cockpit Flooring
No. 126	A18	Control Stick Assembly	No. 320	C6	Battery Box
No. 128	N/A	Induction System IO-320-B1A (Drawing No. assignment only)	No. 321	C7	Fuselage Jig
No. 130	A32	Paint Schemes, Sheet 1	No. 401	D1A	Elevator & Stabilizer Installation
	A33	Paint Schemes, Sheet 2	No. 402	D2F	Elevator & Stabilizer Assy, Sheet 1
	A34	Paint Schemes, Sheet 3		D3D	Elevator & Stabilizer Assy, Sheet 2
	A35	Paint Schemes, Sheet 4	No. 403	D4C	Elevator Ribs & Tip Bow
	A36	Paint Schemes, Sheet 5	No. 404	D5D	Elevator & Stabilizer Ribs
	A37	Paint Schemes, Sheet 6	No. 405	D6F	Elevator & Stabilizer Ribs
No. 131	A9C	Engine Controls Installation	No. 406	D7B	Elevator & Stabilizer Spars
No. 132	A10B	Exhaust System Installation	No. 410	D8A	Fin & Rudder Installation, Sheet 1
No. 133	A11E	Engine Baffling Installation		D9A	Fin & Rudder Installation, Sheet 2
No. 134	A13E	Cowling Installation	No. 411	D10A	Fin & Rudder Assembly
No. 145	A15B	Instrumentation & Installation	No. 412	D11A	Fin & Rudder Spars
No. 150	A20	Control Cables	No. 413	D12E	Fin Ribs
No. 151	A26	Pitot Static System	No. 414	D13G	Rudder Ribs
No. 152	A3E	Fuel System & Engine Hoses Installation	No. 415	D14F	Fin & Rudder Spars, Etc.
No. 153	A30A	Flap Indicator Installation	No. 502	E2E	Main Landing Gear Leg
No. 154		Brake System (Dwg No. assigned)	No. 503	E3B	Main Landing Gear Arm
No. 155	A28	Instrument Panel Installation	No. 503-7	EE16	Axle
No. 156	A29	Seats and Harness Installation	No. 503-8	EE5	Axle
No. 157	A31	L.H. Throttle Installation	No. 503-9	EE6	Seal Ring
No. 158	A27	Vacuum System Installation	No. 503-14	EE5	Brake Plate
No. 160	AA1	Antenna Installation	No. 503-15	EE16	Brake Plate
No. 161	AA3	Ferrite-Foil Antenna Assembly	No. 503-23	EE7	Spacer
No. 162	AA2	DME/Transponder Antenna Assy	No. 503-24	EE17	Spacer
No. 201	B1B	Wing Assembly, Sheet 1	No. 504-1A	EE16A	Lower Side Load Strut
	B2K	Wing Assembly, Sheet 2	No. 504-2	EE3C	Upper Side Load Strut
	B3D	Wing Assembly, Sheet 3	No. 512	EE1E	Main Landing Gear Screwjack Sleeve
	B4B	Wing Assembly, Sheet 4	No. 513	EE2C	Main Landing Gear Screwjack Screw
No. 202	B5A	Wing Tip Bow & Other Details	No. 518	EE3	Main Landing Gear Screwjack Assy
No. 203	B6B	Aileron & Flap Assembly	No. 520-2	E1B	Housing
No. 204	B7B	Aileron & Flap Hinge Installation	No. 520-3	EE18	Spur Gear
No. 205	B8B	Main Wing Spar	No. 520-4	EE19	Miter Gear & Shaft
No. 206	B9F	Auxiliary Wing Spars	No. 520-5	EE4A	Main Gear Drive Shaft
No. 207	B10G	Wing Rib Station 1	No. 520-6A	EE5A	Vertical Drive Shaft
No. 208	B11F	Wing Rib Station 2	No. 520-7	EE20	Miter Gear
No. 209	B12B	Wing Rib Station 3	No. 530	N/A	Landing Gear Motor Assembly
No. 210	B13A	Wing Rib Station 4	No. 550-1	E1B	Oleo Shock Absorber Strut
No. 211	B14A	Wing Rib Station 5	No. 551	EE8	Oleo Orifice Fitting
No. 212	B15A	Wing Rib Station 6	No. 552	EE9	Oleo Rebound Damper
No. 213	B16D	Wing Rib Sta 7 & Aileron Rib Sta 14	No. 553	EE10	Oleo Cylinder
			No. 554	EE11	Oleo Nut
			No. 555-1	EE12	Oleo Piston
			No. 555-2	EE13	Piston End

No. 555-3	EE14	Piston	No. 710-1A	GG123	Coupling
No. 556-1	EE15	Bushing	No. 711-1A	GG124	Torsion Tube
No. 556-2	EE15	Bushing	No. 711-2A	GG124	Torsion Tube
No. 560	N/A	Shoulder Screw (for gear crank)	No. 712	GG35	Aileron Control Rod End
No. 561	N/A	Shoulder Screw (for shock absorber)	No. 713A	GG127	Flap Control Rod
No. 562	N/A	Spring (for shock absorber)	No. 714	GG36	Aileron Control Rod End
No. 565	N/A	5.30x6 Wheel & Brake Assembly	No. 715	GG33	Elevator Control Rod End
No. 601	F1	Nose Gear Assembly	No. 716	GG34	Elevator Control Rod End Fitting
No. 602-1	FF1	Spring	No. 717-1	GG118	Nose Gear Screwjack Support
No. 602-2	FF2	Spacer	No. 717-2	GG119	Bracket
No. 602-3	FF3	Retainer	No. 717-3	GG120	Retainer
No. 603	FF4	Screwjack End	No. 718	GG43	Control Stick Connecting Rod
No. 604A	FF5B	Nose Gear Screwjack Assembly	No. 719A	GG65	Main Landing Gear Arm Pin
No. 605	FF6	Nose Gear Adjustment Screw	No. 720	GG1	Engine Mount Lug
No. 606A	FF7B	Nose Gear Screwjack Sleeve	No. 721	GG68	Main Landing Gear Arm Bushing
No. 607	FF8	Nose Gear Screwjack Screw	No. 722-1	N/A	Exhaust System
No. 608	FF9	Nose Gear Orifice Support Tube	No. 722-2	N/A	Exhaust System
No. 609	FF10	Nose Gear Orifice Support Fitting	No. 722-3	N/A	Exhaust System
No. 610-1	FF11	Nose Gear Orifice	No. 722-4	N/A	Exhaust System
No. 610-2	FF12	Nose Gear Rebound Damper	No. 722-5	N/A	Cabin Heat Muff
No. 613	F4	Nose Gear Fork	No. 723	GG66	Main Landing Gear Oleo Pin
No. 614	FF30	Nose Gear Axle	No. 724-2	GG105	Bracket
No. 615	FF31	Nose Gear Axle Nut	No. 724-3	GG106	Guard
No. 616	FF16	Nose Gear Upper Ring Nut	No. 725-2	GG108	Bracket
No. 618	F3	Nose Gear Upper Drag Strut	No. 725-3	GG109	Guard
No. 618A	F6	Nose Gear Upper Drag Strut	No. 726	GG37	Flap Control Tube Support
No. 619	FF17	Nose Gear Lower Drag Strut	No. 727	GG128	Static Port Fitting
No. 619A	FF34	Nose Gear Lower Drag Strut	No. 728A	G10A	Aft Fuel Tank
No. 620	FF18B	Nose Gear Lower Steering Arm	No. 728-10	N/A	Aft Fuel Tank Sender
No. 621	FF19	Nose Gear Control Rod	No. 729A	G11A	Front Fuel Tank
No. 622	FF33	Screwjack End	No. 729-10	GG129	Tank Vent Fitting
No. 623	FF35	Bushing	No. 729-11	GG130	Filler Fitting
No. 651	FF20	Nose Gear Orifice Assembly	No. 729-12	GG131	Fuel Cap
No. 652-1	FF21	Nose Gear Lower Cylinder Assembly	No. 729-13	N/A	Front Fuel Tank Sender
No. 652-2	FF22	Nose Gear Lower Cylinder	No. 730A	GG132	Fuel Tank Sender Fitting
No. 652-3	FF23	Nose Gear Fork Mounting Plate	No. 731A	GG99	Fuel Tank Filler
No. 653	F3	Nose Gear Upper Cylinder	No. 732	N/A	Gyro Filter Assembly
No. 654	F2	Nose Gear Trunnion	No. 733	GG88	Fuel Tank Band
No. 654A	F5	Nose Gear Trunnion	No. 734	GG94	Fuel Tank Band Mount
No. 655	FF24	Nose Gear Lower Ring Nut	No. 735	GG93	Aft Fuel Tank Band Mount
No. 656	FF25B	Nose Gear Cap Fitting	No. 736	N/A	Wing Tip Lens
No. 657	FF26	Nose Gear Lower Bushing	No. 737	N/A	Cabin Air Valve
No. 658	FF27	Nose Gear Bushing	No. 738	N/A	Cabin Air Valve Plate
No. 659	FF28	Nose Gear Piston Bushing	No. 739	N/A	Spring
No. 660	FF29	Nose Gear Guide & Stop	No. 740	G7D	Hoses, Hose Assemblies, and Tubes
No. 661-2	FF36	Nose Gear Upper Torque Link	No. 741	N/A	Clip
No. 662-2	FF37	Nose Gear Lower Torque Link	No. 742	GG3	Flap Hinge
No. 663	FF13B	Nose Gear Rocker Arm	No. 743	GG4	Flap Hinge & Arm
No. 664	FF14B	Stop	No. 744	GG5	Flap & Aileron Hinge
No. 665	FF15C	Eye Bolt	No. 745	GG6	Aileron Hinge
No. 666	N/A	Wheel	No. 746	GG7	Aileron Control Arm & Hinge
No. 670	FF32	Spacer	No. 747	GG8	Aileron Control Arm & Hinge
No. 701	G5B	Control Stick Support	No. 748	GG9	Aileron Hinge
No. 702	G5B	Control Stick	No. 749	GG10	Aileron Hinge
No. 703-1	G6C	Right Hand Rudder Pedal Assembly	No. 750	GG11	Elevator Control Arm
No. 703-2	G6C	Left Hand Rudder Pedal Assembly	No. 751	GG12	Rudder Control Arm
No. 705	GG62A	Lower Side Load Strut Pin	No. 752	GG13	Elevator Hinge
No. 706	GG63A	Upper Side Load Strut Pin	No. 753	GG14	Fin Hinge
No. 707-1	G1B	Conical Engine Mount	No. 754	GG15	Fin Hinge
No. 707-2	G2C	Dynafoal (Type I) Engine Mount	No. 755	GG16	Stabilizer Hinge
No. 707-3	G29	Dynafoal (Type II) Engine Mount	No. 756	GG17	Elevator Hinge
No. 708	GG2	Nose Gear Drag Strut Support	No. 757	GG18	Rudder Hinge
No. 709-1	GG125	Flap Torsion Tube Assembly	No. 758	GG102	Aileron Bellcrank
No. 709-2	GG122	L.H. Torsion Tube Assembly	No. 759A	GG19	Aileron Bellcrank Support—Bottom



No. 759B	GG20	Aileron Bellcrank Support—Top	No. 828-7	G13C	Seat Track
No. 760	GG30	Elevator Control Bellcrank	No. 828-8	G13C	Seat Track
No. 761	GG21	Rudder Pedal Support	No. 829	N/A	Seat Belts
No. 762	GG22	Elevator Control Arm Support	No. 829-10	GG133	Outboard Seat Belt Cable Assembly
No. 763-1	N/A	Injector Control Bracket	No. 829-11	GG134	Inboard Seat Belt Cable Assembly
No. 764	GG23	Control Stick Assembly Support	No. 829-12	GG135	Shoulder Belt Clip
No. 765	GG31	Flap Control Tube Support	No. 831-1	G27	Center Console Assy & Installation
No. 766	GG72C	Main Landing Gear Aft Mount	No. 831-2	G25	Center Console
No. 767	GG69C	M. Landing Gear Forward Mount	No. 831-3	GG136	Throttle Control Lever Assembly
No. 768	GG70	M. L. Gear Forward Anchor Plate	No. 831-4	GG137	Propeller Control Lever Assembly
No. 769	GG74	M. L. Gear Aft Mount Bushing	No. 831-5	GG138	Mixture Control Lever Assembly
No. 770	GG71	M. L. Gear Forward Mount Bushing	No. 831-6	GG139	Quadrant Bracket
No. 771	GG73	Main Landing Gear Aft Anchor Plate	No. 831-7	GG140	Quadrant Bracket Assembly
No. 772	GG67	Side Load Strut Mount	No. 831-8	GG141	Quadrant Bracket
No. 773	GG64A	Side Load Strut Mount Spacer	No. 831-9	GG142	Quadrant Spacer
No. 774	GG24	Fin Hinge	No. 831-11	GG143	Quadrant Spacer
No. 775	GG25	Elevator Trim Arm	No. 831-13	GG144	Quadrant Friction Knob
No. 776	GG81	N. G. Drag Strut Support Anchor Plate	No. 831-14	GG145	Throttle Position Switch Cam
No. 777	GG117	Canopy Slide Tube	No. 831-15	G14A	Quadrant Cover
No. 778	N/A	Rudder Pedal	No. 831-30	GG50B	Flap Position Switch Support
No. 780	GG32	Elevator Control Rod Assembly	No. 831-31	GG42A	Quadrant Spacer
No. 781	GG103	Aileron Control Rod	No. 832A	G14A	Landing Gear Crank Cover
No. 782	GG75	Trim Tab Control Wheel	No. 833A	G15A	Center Console Cover—Front
No. 783	GG76	Trim Tab Control Channel	No. 834A	G16A	Center Console Cover
No. 784	GG77A	Trim Tab Control Sleeve	No. 835A	G17A	Center Console Cover—Rear
No. 785	GG78B	Trim Tab Control Screw	No. 836	G19A	Main Landing Gear Doors
No. 786A	GG79A	Trim Tab Control Mount Plate	No. 837	N/A	Inspection Doors
No. 788A	GG80A	Trim Tab Control Mounting Bracket	No. 838-2	GG52	Elevator Balance Weight
No. 791-1	GG92A	Pitot Tube Mast	No. 839	GG83	Engine Mount Lug Anchor Plate
No. 792	GG98	Canopy Track	No. 840	G3	Cowling
No. 794	GG86	Canopy Roller Mount	No. 840	G4A	Cowling
No. 795	GG87	Canopy Roller	No. 841-1	G26	Instrument Panel
No. 797-1	G12B	Canopy Frame	No. 842	N/A	Nose Gear Doors
No. 797-2	G22	Canopy Frame—"Nustrini"	No. 845	GG49B	Channel
No. 799	GG114	Canopy Closing Handle	No. 846	GG116A	Channel
No. 800	GG40C	Canopy Closing Hook	No. 850	GG101	Channel-Nut
No. 800A	GG40C	Canopy Closing Hook—"Nustrini"	No. 851-1	GG110	Control Stick Removal Modification
No. 801A	GG41A	Canopy Latch Spring	No. 851-2	GG111	Nut
No. 802	GG84	Canopy Roller Mount	No. 851-3	GG112	Receptacle
No. 803	GG85	Canopy Roller	No. 851-4	GG113	Connector
No. 804	GG18	Carburetor Air Intake	No. 852	N/A	Yoke
No. 805	GG89A	Center Lap Belt Mount	No. 853	N/A	Flap Actuator
No. 806	GG126	Outboard Lap Belt Mount	No. 854	GG121	Flap Actuator Support
No. 807	GG90B	Shoulder Belt Mount	No. 856A	GG82A	Engine Mount Lug Anchor Plate
No. 808	N/A	Engine Baffling	No. 857	G21D	Tail Group Fairings, Etc.
No. 809-1	GG104A	Jack Pad Fitting	No. 858-1	G30	Nose Gear Bay Cover Assembly
No. 809-2	N/A	Tie Down Eyebolt	No. 859-2	GG96A	Bracket
No. 810-1	N/A	Governor Controls Bracket	No. 859-3	GG96A	Bracket
No. 814	G20B	Wing Fairings	No. 859-4	GG97A	Bracket
No. 816	GG38	Mounting Bracket	No. 860	GG53A	Pushrod
No. 817	GG39	Canopy Fitting	No. 861	GG54A	Pushrod
No. 818	GG91A	Aileron Stop	No. 862	GG55A	Pushrod
No. 820	GG44B	Landing Gear Crank	No. 863	GG47B	Bracket
No. 821-2	GG45B	Spindle	No. 864	GG48B	Bracket
No. 821-3A	GG115	Collar	No. 865	GG56A	Pushrod
No. 822	GG46B	Landing Gear Crank Handle	No. 866	GG107A	Bracket
No. 823	GG26	Canopy Stop	No. 867	N/A	Fuel Pump Mounting Bracket
No. 824-1	N/A	Bulkhead Fitting Assy (Cabin Heat)	No. 868	GG100A	Canopy Pin—"Nustrini"
No. 825A	GG51A	Elevator Balance Weight Support	No. 869	GG95A	Canopy Fitting—"Nustrini"
No. 826	N/A	Cabin Heat Cable Bracket	No. 870	GG57A	L.H. Throttle Pivot Cover
No. 828-1	G9B	Seat	No. 871	GG58A	L.H. Throttle Pivot Fitting
No. 828-2	G9B	Seat	No. 872-1	GG59A	Torque Tube Assembly
No. 828-3	G23	Seat Bottom Cushion	No. 873-1	GG60A	L.H. Throttle Pushrod
No. 828-4	G24	Seat Back Cushion	No. 874	GG61A	L.H. Throttle Pushrod

No. 875-1	GG27A	L.H. Throttle Control Lever Assy
No. 876	GG28B	Drain Valve Fitting
No. 877	GG29C	Up Limit Switch Support
No. 878	N/A	Nustrini Canopy Skirt Fairing
No. 879	N/A	Fuel Filter Support Bracket
No. 880	N/A	Washers
No. 881	N/A	Disks
No. 883-1	N/A	Antenna Rod
No. 883-2	N/A	Antenna Plate
No. 884	G28	Glare Shield
No. 885-1	N/A	Throttle Control Cable
No. 885-2	N/A	Propeller Control Cable
No. 885-3	N/A	Mixture Control Cable
No. 885-4	N/A	Tachometer Cable
No. 885-5	N/A	Carburetor Heat Cable
No. 885-6	N/A	Defrost Cable
No. 885-7	N/A	Cabin Heat Cable
No. 885-20	N/A	Tachometer Angle Drive
No. 885-30	N/A	Cable Swivel Fitting
No. 885-31	N/A	Cable Stud
No. 886	N/A	Wing Fillet
No. 887	N/A	Vacuum Regulator
No. 888	N/A	Elbow Fitting
No. 889	N/A	Elbow Fitting
No. 890-1	N/A	Fuel Selector Valve
No. 891	N/A	Elbow Fitting
No. 892	N/A	Bulkhead Fitting
No. 893		
No. 894		
No. 895-1	N/A	Panel Light Bracket